

## Instructions ...3 Fast and Easy Steps...



Remove Cap and Dip Strip into Specimen  
Hold for 30 Seconds



Replace Cap and Lie Test on Flat Surface  
Wait 5 Minutes for Result



Negative Result: Both Lines (C & T) Appear  
Positive Result: Only "C" line Appears